Menu Structure of Monitor BenQ BL3201PT

Main Menu			
Display	PIP / PBP	Mode	PIP (Picture In Picture)PBP (Picture By Picture)• OFF
		PIP / PBP Source	• DVI HDMI1 HDMI2 DisplayPort
		SWAP PIP Size	Large • Medium Small
		PIP Position	• Top Right Top Left Bottom Right Bottom Left
	Auto Pivot	• ON / OFF	
	Input	DVI HDMI1 HDMI2 DisplayPort Mini DisplayPort	
Picture	Brightness Contrast	0100 (100) 0100 (50)	(not if DynamicContrast or Eye Protect) (not if DynamicContrast)
	Gamma	$ \begin{array}{c} 1.10(3) \\ 1 (1.0) \\ 2 \\ \bullet 3 (2.2) \\ 4 \\ 5 (2.7) \end{array} $	(only in picture mode Standard)
	Color Temperature	• Normal Bluish Reddish User Define	(only in picture mode Standard & User) (only in picture mode User) R 0100 (red, 100) G 0100 (green, 100)
	Нир	0 100 (50)	B 0100 (blue, 100)
	Saturation	0 100 (50)	
	Reset Color	YES / • NO	
	АМА	OFF • High Premium	Advanced Motion Acceleration (pixel overdrive)

Picture Advanced	Picture Mode	sRGB	
		CAD / CAM	
		Animation	010 (1)
		Presentation	
		 Standard 	
		Low Blue Light	Multimedia -30 % Web Surfing -50 % Office -60 % Reading -70 %
		Movie	
		Photo	
		Eco	
		M-book	(McBook adaption)
		User	
	Senseye Demo	ON / • OFF	(only in some picture modes)
	DynamicContrast	• 0, 1, 5	(only in picture mode Movie or Photo)
	Overscan	ON / • OFF	(only if HDMI input)
	Display Mode	• Full Aspect 1 : 1 19s" 22"(16 : 10) 23" 24" 24"(16 : 10) 27" 27"(16 : 10) 30"	
	Smart Scaling	?	
	HDMI RGB PC Range	• RGB(0 ~255) RGB(16 ~235)	(only if HDMI input)
Audio	Volume	0 100 (20)	
Audio	Muto	ON / • OEE	
	Audio Select		

System	OSD Settings	Language	English
System	USD Settings	Display Time	5 sec / 10 sec / ● 15 sec / / 30 sec
		OSD Lock	OSD locked! Hold any key 10 sec. to unlo
	Custom key 1 Custom key 2 Custom key 3	Picture Mode CAD / CAM Animation Low Blue Light Display Mode Brightness	key 1
		Volume Mute	key 3
		Input Eye Protect Eye Protect Meter ECO Sensor ECO Sensor Meter Smart Reminder	key 2
	DDC / CI	• ON / OFF	
	DP Auto Switch	• ON / OFF	
	HDMI Auto Switch	ON / • OFF	
	Auto Power off	• OFF 10 min. 20 min. 30 min.	
	Resolution Notice	• ON / OFF	
	Information	Input Current Resolution Optimum Resolution	 3 8 4 0 x 2 1 6 0 @ 60 3 8 4 0 x 2 1 6 0 @ 60
	DisplayPort	1.1 / • 1.2	
	Controller key 1 Controller key 2 Controller key 3	sRGB CAD / CAM Animation Presentation Standard	key 1 key 2
		Low Blue Light Movie Photo Eco M-book User Brightness Volume	key 3
	Reset All	YES / • NO	Reset All Settings ?

ERGONOMICS	Eye Protect	ON / • OFF	(only in picture mode Standard,
	Eye Protect Meter	ON / • OFF	automatic brightness)
	Smart Reminder	ON / • OFF	
	Time Interval (min.)	• 20 min.	
		20 min.	
		40 min.	
		60 min.	
		80 min.	
		100 min.	
	Duration (sec.)	• 5 sec.	
		10 sec.	
		15 sec.	
		20 sec.	
		25 sec.	

ECO	ECO Sensor	ON / • OFF
	ECO Sensor Meter	ON / • OFF
	Sensor Range	Near / Middle / • Far

Picture Modes of Monitor BenQ BL3201PT

Picture Mode Picture	sRGB	CAD / CAM	Animation	Presen- tation	Standard	Low Blue Light	Movie	Photo	Eco	M-book	User
Brightness	•	•	•	•	(•)	•	(•)	(•)	-	•	•
Contrast	•	•	-	•	•	•	(•)	(•)	-	•	•
Sharpness	•	•	•	•	•	•	•	•	•	•	•
Gamma	-	-	-	-	•	-	-	-	-	-	•
Color Temperature	-	-	-	-	•	-	-	-	-	-	•+
Hue	-	-	-	-	-	-	-	-	-	-	•
Saturation	-	-	-	-	-	-	-	-	-	-	•
SensEye Demo	-	•	•	-	-	-	•	•	-	•	-
DynamicContrast	-	-	-	-	-	-	•	•	-	-	-
Eye Protect	-	-	-	-	•	-	-	-	-	-	-

Picture Modes of Monitor BenQ BL3201PT – re-sorted

Picture Mode Picture	Standard	User	sRGB	Low Blue Light	Presen- tation	Movie	Photo	CAD / CAM	Animation	M-book	Eco
Brightness	(•)	٠	•	•	•	(•)	(•)	•	•	•	-
Contrast	•	•	•	•	•	(•)	(•)	•	-	•	-
Sharpness	•	•	•	•	•	•	•	•	•	•	•
Gamma	•	•	-	-	-	-	-	-	-	-	-
Color Temperature	•	●+	-	-	-	-	-	-	-	-	-
Hue	-	•	-	-	-	-	-	-	-	-	-
Saturation	-	•	-	-	-	-	-	-	-	-	-
SensEye Demo	-	-	-	-	-	•	•	•	•	•	-
DynamicContrast	-	-	-	-	-	•	•	-	-	-	-
Eye Protect	•	-	-	-	-	-	-	-	-	-	-

Controller Key Assignment

	default: picture modes	example
Controller key 1	sRGB	User
Controller key 2	CAD / CAM	Standard
Controller key 3	Low Blue Light	Brightness

Panel Key Assignment

	default	example
Custom key 1	Picture Mode	Display Mode
Custom key 2	Input	Picture Mode
Custom key 3	Volume	Input
key 4	Main menu	
key 5	Exit	